




MINI FRIDGE

MODEL: iceQ49g



INSTRUCTION MANUAL

Please read this manual carefully before using this fridge

- 1) This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- 2) **WARNING:** Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction
- 3) **WARNING:** Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- 4) **WARNING:** Do not damage the refrigerant circuit.
- 5) **WARNING:** Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- 6) Please abandon the refrigerator according to local regulators for it use flammable blowing gas and refrigerant.
- 7) Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance
- 8) This appliance is intended to be used in household and similar applications such as staff kitchen areas in shops, offices and other working environments; farm houses and by clients in hotels, motels and other residential type environments;
bed and breakfast type environments;
catering and similar non-retail applications.

This appliance is intended to be used exclusively for the storage of wine or other beverages.



WARNING:

RISK OF ELECTRICAL SHOCK HAZARD

USERS IN NORTH AMERICA This unit must be plugged into a grounded 220V AC circuit. If the power cable is damaged, it must be replaced by a qualified engineer to avoid shock hazard. **DO NOT ATTEMPT TO SERVICE THE ITEM YOURSELF.** Ensure that the appliance is properly grounded. Stop using the appliance immediately if electric shock is felt when touching the cooler.

USERS IN EUROPE This unit must be earthed.

If the power cable is damaged, it must be replaced by a qualified engineer to avoid shock hazard. **DO NOT ATTEMPT TO SERVICE THE ITEM YOURSELF.** Ensure that the appliance is properly earthed. Stop using the appliance immediately if electric shock is felt when touching the cooler.

DISPOSAL OF OLD REFRIGERATORS

BE SURE TO MAKE ANY LOCKS UNUSABLE. IF POSSIBLE, REMOVE THE DOOR(S) AND DISCARD SEPARATELY.

WARNING – CHEMICAL HAZARD: DO NOT ALLOW CHILDREN TO PLAY WITH THE OLD APPLIANCE. CONTACT YOUR LOCAL AUTHORITY FOR PROPER DISPOSAL PROCEDURES.

Before disposing of an old appliance, please make sure it is switched off and safe. Unplug the appliance and break any locks in order to avoid children becoming trapped.

Please note: the cooling system contains gases and refrigerants which require specialist waste disposal. The valuable materials contained in a refrigerator can be recycled.

Contact your local waste disposal depot for proper disposal of an old appliance and contact your local authority or dealer if you have any questions.

Please ensure the pipework of your cooler is not damaged prior to disposal. You can contribute to environmental awareness by insisting on an appropriate non-polluting method of disposal.

DISPOSAL OF PACKAGE

All the package materials with your Refrigerator may be disposed of without danger to the environment.

The cardboard may be broken or cut into smaller pieces and given to a waste paper disposal service. The wrapping foil is made of polyethylene. The polyethylene pads and stuffing contain no fluorochloric hydrocarbons.

All these valuable materials may be taken to a waste collecting depot and used again after adequate recycling.

Consult your local authority for the name and address of the waste paper disposal services nearest to you.

SAFETY INSTRUCTION & WARNINGS

Before switching on your Refrigerator, read the information in this User Guide carefully. The User Guide contains important observations relating to the assembly, operation and maintenance of the appliance.

Warranty

This appliance is guaranteed to be free from defects in parts and manufacture for 12 months from date of purchase, provided that the unit is used under the normal operating conditions shown within the manual. Your attention is drawn to the following:

- will not accept any liability for damage or injury caused by improper use.
- will not be liable for any damage caused by moving the appliance; improper power supply; defective wiring or fuses; accident, alteration, abuse or misuse of the appliance; abnormal operating conditions; commercial or industrial use; fire; water damage; or customer misuse.
- This warranty is void if service on the unit is performed by any person other than an approved technician, or if the appliance is used for commercial purposes.

This warranty is available only to the original purchaser and is not transferable. Your normal consumer rights are not affected.

If service is required, **DO NOT ATTEMPT TO REPAIR UNIT YOURSELF.** Please return unit to store. Proof of purchase will be required for any warranty claims. You must retain your original receipt. If service under warranty is required, you will be required to produce this. Please also retain the original packaging should the unit need to be returned.

Please note: As part of our policy of continuous product improvement, reserves the right to amend specifications without notice.

If the unit is not being used for long periods:

- Unplug your Refrigerator.
- Clean and dry the inside of the appliance. Leave the door slightly open to allow it to dry completely.
- A cooler which is unused without being cleaned may start to smell musty or develop mildew.

DEFROSTING

The surface of the evaporator ices up when the refrigerator is working. This is an entirely normal part of operation. If the frost layer is more than 3mm/ $\frac{1}{8}$ " thick, the cooler must be defrosted and cleaned to avoid unnecessary energy consumption and inefficient operation.

1. Remove all items inside and unplug the unit.
2. After defrosting, clean the unit (see instructions below) and allow it to dry. Reconnect to the mains supply with the temperature control at "5", then follow the directions 'To operate' and 'Tips for refrigeration' above).

Cleaning

1. Unplug your Refrigerator.
2. Wash the interior with warm water and neutral detergent.
3. Dry all surfaces thoroughly.

Note: Do not use abrasive cleaners!

To ensure efficient operation the back and bottom of the cooler should be cleaned thoroughly. Use mild soapy water to clean the door seal.

Moving your Refrigerator

- Unplug the appliance
- Remove all items inside

Note: Never hold the appliance by the door.

Power Failure

If a power cut occurs, do not open the door more often than necessary in order to conserve cold air.

TROUBLESHOOTING

Before returning your Refrigerator to the store, check the following points; you may be able to solve any problem yourself.

Problem

Solution

Not cooling

- Check power cable is connected and fuse is intact.
- Wrong temperature selected.
Adjust setting on controller to position shown (see page 5)
- Cooler is overfilled.
- Appliance exposed to direct sunlight or a heat source.
- Door is opened too often.

Unusual noises or noisy operation

- Appliance is not on a level, firm surface or may be touching other items.
- Note: It is normal to hear refrigerant flowing as the compressor stops and starts.

Outer surfaces are wet

- Water source or leak too near the appliance – dry surfaces thoroughly and move the appliance.

Inner surfaces are wet

- Door opened too often or kept open too often.

Please keep this booklet in a safe place for future reference. If you ever sell this unit, hand this User Guide to the new owner.


The manufacturer does not accept responsibility for any damages that may arise due to non-observation of these instructions.

WARNING: When positioning the appliance ensure the supply cord is not trapped or damaged. Do not locate extension sockets or charging transformers/power supplies adjacent to the compressor at the back of the unit, as they could overheat.

- Do not use damaged appliances. If you are in any doubt, consult the supplier.
- Connection and installation of the unit is to be carried out in strict compliance with the relative instructions in this User Guide.
- For safety, the appliance must be properly earthed in accordance with specifications.
- Always remember to unplug the appliance before cleaning. Never unplug your cooler by pulling on the power cable. Always grip plug firmly and pull straight out from the socket.
- All electrical repairs must be carried out by qualified engineers. Inadequate repairs may be dangerous.
- DANGER OF FERMENTATION: Keep alcoholic beverages in airtight bottles or containers.
- Do not damage any parts of the appliance which carry refrigerant by piercing, perforating, crushing, twisting or scraping. If the refrigerant comes into contact with the eyes, it may cause serious eye injury.
- Do not obstruct or cover the ventilation aperture.
- Do not allow children to play with your Refrigerator, or to sit on it or hang onto the door.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

SPECIFICATIONS

- This appliance is designed as a cellar for the storage of wine and other beverages.
- It is intended strictly for domestic use.
- The refrigerating circuit is leak-proof.



REVERSING THE DOOR HINGE

The door can be opened from left to right and vice versa. Should you wish to change the opening direction, please follow the instructions overleaf.

Note: all parts removed should be kept safely. You will require these for the reinstallation of the door.






Fig 1 Position of components prior to reversal of the door hinge.




Fig 2 Position of components after reversal of the door hinge.

- Remove the two screws (1) that hold the upper hinge (5)(right side) to the frame.
- Lift the door off and place on a padded surface to prevent scratching.
- Remove the blanking plug (7) from the hole in the upper left corner of the door and transfer it to the uncovered hole on the upper right corner. Press firmly to secure it.
- Remove the two screws (6) and the adjustable foot (3) that hold the lower hinge (2)
- Remove the adjustable front left foot (4) and transfer it to the other side.
- Secure the lower hinge (2) to the left side of the lower frame with the two screws (6) and the adjustable foot (3). Set the door into position, making sure it is seated comfortably onto the lower hinge (2).
- Holding the door closed, secure the upper hinge (5) into the top frame with the two screws (1). Check the door is level and tighten the screws firmly.

BEFORE USING FOR THE FIRST TIME

- For good circulation, the vent at the back of the unit must not be blocked. Your Refrigerator should be placed on flat and firm surface for quieter operation.
- Do not expose the appliance to direct sunlight or a heat source such as ovens, radiators, heaters, etc.
- Do not under any circumstances place heated beverages in your Refrigerator.
- Do not open the door more often than necessary to lessen the escape of cold air.
- For better air circulation, do not overfill the unit.
- Adjust the temperature thermostat according to the amount of product and the ambient temperature.

BASIC OPERATION

Your Refrigerator must stand on an even surface.

If the appliance is to be placed on carpet, support it with a wooden board underneath. Be aware that placing the appliance on carpet may mean that heat from the compressor may cause the carpet to fade.

Thermostat settings

Thermostat OFF position indicates the refrigerator is turned off. Turn the temperature control clockwise, starting from this setting, the device will turn on

automatically. The settings 1 (MIN) – 5 (MAX) regulate the interior temperature.


Setting OFF = Off (no power)

Setting 1 (or MIN) = lowest setting (warmest internal temperature)

Setting 5 (or MAX) = highest setting (coldest internal temperature)

To operate

1. Clean the inner compartment.
2. Plug in your Refrigerator.
3. The first time you turn the unit on, turn the thermostat, situated at the back of the unit, clockwise to the max. position "5".
4. After 20 minutes, adjust the temperature control setting to "3". This setting should be correct for general domestic use.
5. To turn the unit off, turn the thermostat to the "OFF" position and/or disconnect the plug from the mains supply.



NOTE: If the unit is unplugged or power lost, you must wait 3 to 5 minutes before restarting. If you attempt to restart the unit before this delay, the unit will not start.

Tips for refrigeration

Adjust the internal temperature according to the amount of product and the ambient temperature.

Winter (5-10°C/41-50°F) — Setting 1-2

Spring and Autumn (10-15°C/50-59°F) — Setting 2-4

Summer (15-25°C/59-77°F) — Setting 4-5

The inner temperature varies in different parts of the refrigerator. The back of the refrigerator is coldest.

WARNING

If temperature selector is set to too low a setting, beverages become frozen. In extreme circumstances, glass bottles may even break. Always exercise caution when setting the temperature.



- Do not place heavy items (more than 20kg/44lbs) on top of the cooler.
- Do not place any items on top of the cooler which may fall off when the door is opened.
- After the appliance has been unplugged, leave for three minutes before plugging it in again.

Interior light

The interior light is positioned in the unit's inner ceiling. The lights are low voltage LEDs and should not need replacing during the life of the unit.

The ON/OFF switch is positioned on the back of the unit, on the right side of the thermostat housing.

